Commercial and banking intrusion detection certified.

The Protege WX and Protege GX DIN Rail Controllers have multiple certifications. But what are they and what benefit do they bring to you?

The certification.

UL2610: Commercial Premises Security Alarm Units and Systems for United States of America.

The meaning and benefit.

ICT's Protege WX and Protege GX controllers meet industry standard requirements for the construction, performance, operation, and maintenance of:

> Central station or local burglar alarm systems to be used in commercial and banking premises, including safes and vaults, as well as those connected to police stations

> Proprietary burglar alarm units and systems

> Police station connected burglar alarm units and systems for use in mercantile premises, mercantile safes and vaults, and bank safes and vaults

> Remote-station holdup alarm systems for use in banks, commercial premises, pay offices etc

> Digital alarm communicator system units to be used in a system

> Power supplies used to provide electrical and standby power for the systems

Overall, this standard ensures that the intrusion detection systems used in commercial and financial institutions are constructed, operated and maintained accordingly.

This standard works in conjunction with UL1610 - Standard for Central-Station Burglar-Alarm Units. These ensure that when an alarm is triggered, the controller records and reports intrusion detection activity to your Protege WX or Protege GX system, as well as the central monitoring station, who can then alert the proper authorities. No mix-ups or confusion between disparate systems and monitoring stations, giving you peace of mind that nothing will be missed.

Target applications.

This standard is specifically aimed at:

> Commercial sites such as retail stores, restaurants and bars, or hotels

> Banks and financial institutions

For intrusion detection standards for residential or other sites, please see:

> UL1076: Proprietary Burglar Alarm Units and Systems

To see the list of requirements for setting up the Protege WX or Protege GX controller for either certification, please see:

> PRT-CTRL-DIN: Protege GX DIN Rail Integrated System Controller Installation Manual

> PRT-WX-DIN: Protege WX DIN Rail Integrated System Controller Installation Manual