


AN-277

Configuring Protege GX to use TLS 1.2

Application Note



The specifications and descriptions of products and services contained in this document were correct at the time of printing. Integrated Control Technology Limited reserves the right to change specifications or withdraw products without notice. No part of this document may be reproduced, photocopied, or transmitted in any form or by any means (electronic or mechanical), for any purpose, without the express written permission of Integrated Control Technology Limited. Designed and manufactured by Integrated Control Technology Limited, Protege® and the Protege® Logo are registered trademarks of Integrated Control Technology Limited. All other brand or product names are trademarks or registered trademarks of their respective holders.

Copyright © Integrated Control Technology Limited 2003-2025. All rights reserved.

Last Published: 25-Sep-25 9:46 AM

Contents

Introduction	4
Prerequisites	4
TLS 1.2 Setup	5
Using a Custom Certificate	6
Custom Wildcard Certificates	7
Enabling Certificate Validation on the Client	7
Configuring the Protege GX SOAP Service	8
Renewing TLS Certificates	9
Logging in with Windows Authentication	10

Introduction

Transport Layer Security (TLS) is a cryptographic protocol that protects communications when data is transferred between programs or computers on a network.

TLS version 1.2 is the default security setting for Protege GX software communication channels. This application note outlines the steps to fully configure Protege GX to use TLS 1.2.

Prerequisites

To enable TLS 1.2 the following are required:

Software Component	Version	Notes
Protege GX	4.3.264.9 or higher	
Microsoft SQL Server	32-bit installations: 2012 SP4, 2014 SP2, or a later edition that supports TLS 1.2 64-bit installations: 2016 SP2 or a later edition that supports TLS 1.2	For the SQL server editions that support TLS 1.2, see the Microsoft Documentation . For the SQL server editions supported by Protege GX, see the Protege GX Server Installation Manual.

TLS 1.2 Setup

TLS 1.2 is the default security option in the Protege GX installation process, and required items are automatically set up in the background unless a different option is selected. If TLS 1.2 is not currently enabled in your installation, you can enable it by reinstalling the application and ensuring that TLS 1.2 is selected.

To check whether TLS 1.2 was enabled during installation, navigate to the installation directory (C:\Program Files (x86)\Integrated Control Technology\Protege GX) and open GXSV.exe.config in a text editor. If the file contains the text `sslProtocols="Tls12"`, then TLS 1.2 was enabled.

As part of the Protege GX install process a number of items are installed or configured. These include:

- Installing Microsoft .NET Framework 4.6.2.
- Installing OLE DB Driver 18.
- Creating a self-signed certificate on the local PC.
- Adding configuration entries into the Windows registry.
- Adding required configuration entries into the Protege GX config files.

In addition to the above the following manual steps are required to fully enable TLS 1.2 for Protege GX.

Different configuration is required to use TLS 1.2 with Windows Authentication. For more information, see [Logging in with Windows Authentication \(page 10\)](#).

Enabling Force Encryption and TCP/IP

1. Open SQL Server Configuration Manager:
 - Press **Windows + R** to open the run dialogue.
 - Type `sqlservermanager<version>.msc`, replacing `<version>` with the version number of the application corresponding to your SQL Server installation (see [this page](#)).
 - Click **OK**.
2. Open the **SQL Server Network Configuration** section from the left-hand pane.
3. Right click on **Protocols for ProtegeGX** (or the SQL instance name that holds the Protege GX database), and select **Properties**.
4. In the Properties window set **Force Encryption** to Yes and click **OK**.
5. Open **Protocols for Protege GX**.
6. Double click **TCP/IP** and set **Enabled** to Yes. Click **OK** to close the window.
7. Open **SQL Server Services** from the left-hand pane.
8. Right click on **SQL Server (ProtegeGX)** in the right-hand pane and select **Restart** to restart the Protege GX SQL Server Service.
9. When complete, close the SQL Server Configuration Manager.

Enabling the IIS Management Console

1. Enable the IIS Management Console by navigating to: **Control Panel > Programs and Feature > Turn Windows Features On or Off**.
2. In the feature list, navigate to **Internet Information Services > Web Management Tools > IIS Management Console**. Check the box to enable this feature.
3. Click **OK**.
4. Restart all Protege GX services.

Using a Custom Certificate

In some systems, it is preferred to use a custom TLS/SSL certificate instead of the self-signed certificate generated by Protege GX during installation. Some additional configuration is needed to install the custom certificate.

This is required when there are Protege GX clients connecting to the server from outside the router/firewall and port forwarding is in place. The custom certificate must refer to the external hostname of the Protege GX server.

The exact process may vary depending on your operating system. Consult your IT provider for more detailed instructions.

Obtaining the Server Certificate

An SSL certificate in the form of a .pfx file must be obtained from your IT provider. This can be self-signed or provided by a trusted certificate authority. You will also require the password used to generate the file, in order to install the certificate.

Installing the Server Certificate

1. Copy the .pfx file to the Protege GX server you are installing the certificate on.
2. Double click the certificate to initiate the **Certificate Import Wizard**.
3. Set the **Store Location** to Local Machine.
4. Do not change the **File to Import**.
5. Enter the password used to generate the .pfx file. The person who generated the certificate should know this.
6. Set the place where you wish to store the certificate as the **Personal folder**.
7. Complete the import.

Configure Protege GX to use the Certificate

Once the certificate is installed you will need to configure Protege GX to use that certificate for its connections.

1. Open **Microsoft Management Console** by pressing **[WIN + r]**, typing mmc and pressing enter.
2. Once the console is open, open **Add or Remove Snap-ins** by pressing **[CTRL + m]**, or via the **File** menu.
3. Double click **Certificates**, select **Computer Account** and click **Next**.
4. Select **Local Computer** and click **Finish**.
5. Click **OK** to close the snap-ins window.
6. Navigate to **Certificates (Local Computer) > Personal > Certificates**.
7. You should be able to see your installed certificate here. Double click on it.
8. Find the field named **Thumbprint** and copy the data from it to a safe place.
9. Open **GXSV.exe.config**, located in the installation directory (C:\Program Files (x86)\Integrated Control Technology\Protege GX).

Files in this directory require administrator permissions to edit. You may need to open the file as an administrator using an application like Notepad++, or make a copy in a different directory to edit and replace the original.

10. Locate the following section in the XML:
/configuration/system.serviceModel/behaviors/serviceBehaviors/behavior[@name="md"]/serviceCertificate
If this section does not exist it is because you did not install Protege GX with TLS enabled.

11. In the `<serviceCertificate>` tag, change the `findValue` to the thumbprint of the new certificate you installed. The result will look similar to the following:

```
<serviceCertificate
  storeLocation="LocalMachine" storeName="My" findValue="CERTIFICATE_
  THUMBPRINT" x509FindType="FindByThumbprint" />
```

12. **Save** the config file and **restart** the Protege GX Data Service for the changes to take effect.

Custom Wildcard Certificates

It is possible to install custom wildcard TLS certificates in the same way as the standard custom certificates above. In addition, you must change the hostname in `GXPI.exe.config` and `GXRpt.exe.config` from `localhost` to the full hostname.

This should be completed for both config files for **each client installation**. The easiest method is to update the files on one client machine, then copy them to other machines as necessary.

The following sections need to be updated in each file:

- `configuration/system.serviceModel/client/endpoint@address`: This should be the full hostname that you are actually connecting to.
- `configuration/system.serviceModel/client/endpoint/identity/dns@value`: This should be the first entry listed in the certificate's Subject Alternative Names section.

When using a wildcard certificate, when an operator opens the client they must leave the **Server** field blank. If this field is filled, the client will fail to connect correctly.

Example:

```
<endpoint
  address="net.tcp://servername.domainname:8000/GXSV/GXService"
  behaviorConfiguration="md0"
  binding="netTcpBinding"
  bindingConfiguration="Binding1"
  contract="ServiceReference2.IGXService">
  <identity>
    <dns value="*.domainname" />
  </identity>
</endpoint>
<endpoint
  address="net.tcp://servername.domainname:8010/GXSV/GXService2"
  behaviorConfiguration="md0"
  binding="netTcpBinding"
  bindingConfiguration="Binding1"
  contract="GXServiceRef2.IGXService2">
  <identity>
    <dns value="*.domainname" />
  </identity>
</endpoint>
```

Enabling Certificate Validation on the Client

When a custom trusted certificate is in use, it is recommended to enable service certificate validation to harden the connection between the Protege GX server and client. This protects against man-in-the-middle attacks during the initial connection.

This is only available when a third-party certificate provided by a trusted authority is used, or a self-signed certificate that has been installed as a trusted certificate on client workstations. If the same client workstation is used to connect to multiple Protege GX servers, this setting requires all servers with TLS enabled to use a trusted certificate.

To enable service certificate validation, complete the following configuration on all client workstations:

1. Open **GXPI.exe.config**, located in the installation directory (C:\Program Files (x86)\Integrated Control Technology\Protege GX).

Files in this directory require administrator permissions to edit. You may need to open the file as an administrator using an application like Notepad++, or make a copy in a different directory to edit and replace the original.

2. Directly after the **<configSections>** node, add the **<appSettings>** node as shown below:

```
<configSections>
  <section
    name="microsoft.scripting"
    type="Microsoft.Scripting.Hosting.Configuration.Section,
Microsoft.Scripting, Version=1.0.0.0, Culture=neutral, PublicKeyToken=null"
    requirePermission="false" />
</configSections>
<appSettings>
  <add key="client.validateServiceCertificate" value="true" />
</appSettings>
```

3. Save the config file.

The customized config file may be overwritten when the software is upgraded. You may be required to add the **<appSettings>** node to each client again after the upgrade.

Configuring the Protege GX SOAP Service

This section describes the additional configuration required to deploy the Protege GX SOAP Service for TLS 1.2.

1. When installing the Protege GX SOAP Service, ensure that you install with **TLS enabled**.

On the **Customize WCF TCP/IP Port** page, point the SOAP service to the Protege GX server:

- **Protege GX Data Server installed PC name:** the DNS name or hostname of the Protege GX server
- **Data Server Port:** 8000 (or as configured)
- **Report Server Port:** 8010 (or as configured)

For instructions on installing the SOAP Service, see the Protege GX SOAP Service Installation Manual.

2. Locate and edit the following file: **C:\inetpub\wwwrootProtegeGXSOAPService\Web.config**.
 - Under **/configuration/system.serviceModel/**, comment out or remove this line:
<serviceHostingEnvironment multipleSiteBindingsEnabled="true" />.
 - When using TLS security (recommended) on the data service:
 - Under **/configuration/system.serviceModel/client/endpoint@address**, set the endpoint hostname to the DNS name or hostname of the Protege GX server.
 - Under **/configuration/system.serviceModel/client/endpoint/identity/dns@value**, set the endpoint DNS-identity to one of the 'Subject Alternative Names' in the data service's TLS Certificate.

- The following node should not exist when using a custom certificate. Remove if present:
`/configuration/system.serviceModel/behaviors/endpointBehaviors/behavior[@name=md0]/clientCredentials/serviceCertificate/authentication.`

Renewing TLS Certificates

Sometimes it is necessary to renew or update the TLS certificate associated with a Protege GX installation. This can happen when:

- The existing certificate expires.
- The server's IP address or hostname changes so that the existing certificate is no longer valid.

If you are using the default self-signed certificate generated by your Protege GX installation, you must uninstall and reinstall Protege GX to generate a new self-signed certificate.

If you are replacing a custom certificate, you will need to install and configure the new certificate as described above (see page 6). To complete the process, restart the Protege GX Data Service.

Logging in with Windows Authentication

The Protege GX Active Directory Operator integration enables operators to log in to Protege GX using Windows Authentication, with no need for a username or password. This is an optional licensed feature.

With some additional configuration, you can enable both TLS 1.2 and Windows Authentication in your Protege GX installation. First, complete the instructions in this app note. Then follow the additional instructions in the **Active Directory Operator Integration** section in Application Note 288: Using Active Directory in Protege GX.

Designers & manufacturers of integrated electronic access control, security and automation products.
Designed & manufactured by Integrated Control Technology Ltd.
Copyright © Integrated Control Technology Limited 2003-2025. All rights reserved.

Disclaimer: Whilst every effort has been made to ensure accuracy in the representation of this product, neither Integrated Control Technology Ltd nor its employees shall be liable under any circumstances to any party in respect of decisions or actions they may make as a result of using this information. In accordance with the ICT policy of enhanced development, design and specifications are subject to change without notice.